






MCU SWD



Reset







Company Name: GigaDevice

File Name: GDLink

Revision: 1.0




Data: 2023-07

Author: sijia.wang



SWD GDLink

SWDIO	L_TMS/IO
SWCLK	L_TCK/CLK
NRST	L_TRreset



Company Name: GigaDevice

File Name: MCU


Revision: 1.0

Data: 2023-07











Author: sijia.wang

Arduino


LED



KEY



USART To USB




Company Name: GigaDevice

File Name: Peripherals

Revision: 1.0

Data: 2023-07

Author: sijia.wang



Company Name: GigaDevice


File Name: Power

Revision: 1.0

Data: 2023-07

Author: [sijia.wang](#)

USB



Company Name: GigaDevice

File Name: USB

Revision: 1.0

Date: 2023-07

Author: sijia.wang

GD32

GD32MCU.com

GD32L235Q-START

2023-07 V1.0

